



CONNECTOR GUIDE

CONNECTOR	DESCRIPTION	AUTOMATED TRIM TOOL (SG-ICA, WCW-ICA, WCW-LCF)	MANUAL TOOL FOR DRAGONSKIN (WCW-2HB12-50JPLR)
WCW-NM-LCF12-D01 •	N Male Connector; D01 Series	WCW-TRIM-LCF12-D01-A •	WCW-TRIMSET-2HB12E01
WCW-NF-LCF12-D01 •	N Female Connector; D01 Series		
WCW-NMR-LCF12-D01 •	N Male Right Angle Connector; D01 Series		
WCW-43M-LCF12-D01 •	4.3-10 Male Connector		
WCW-716M-LCF12-D01 •	7-16 DIN Male Connector	WCW-TRIM-LCF12-D01-A •	—
WCW-NM-LCF12-C02-6 *	N Male Connector; C02-6 Series	WCW-TRIM-ICA12-C02 *	WCW-TRIMSET-2HB12C03 ▽
WCW-NF-LCF12-C02-6 *	N Female Connector; C02-6 Series		
WCW-NM-LCF12-C03 ▽	N Male Connector; C03 Series	WCW-TRIM-ICA12-C02 *	Not Approved for DragonSkin
WCW-NF-LCF12-C03 ▽	N Female Connector; C03 Series		

DESCRIPTION OF 3 SERIES OPTIONS: REFER TO THE END CHARACTERS OF EACH PART NUMBER

D01	Premium; two-piece connector. INSTALLATION RATING – NOVICE • One-piece prep tool, which includes the flaring tool. (All cables)
C02-6	Standard; four-piece connector. INSTALLATION RATING – COMPETENT * Recommend connector for 2HB12-50JPL. One piece prep tool flaring tool are sold separately. (All cables)
C03	Standard; four-piece connector, budget-friendly. INSTALLATION RATING – PROFICIENT ▽ One piece prep tool flaring tool sold separately. (All cables except WCW-2HB12-50JPL)



- Check out our [DAS RESOURCE PAGE](#): download VEX Files, request a ROM/BOM, or ask a DAS question
- Ask about our **OEM TRAINING/CERTIFICATION**
- Find more DAS information:

[DAS Plenum Cables](#) • [Outdoor Coax](#) • [SmartGUARD Coax Cables](#) • [50 Ohm Braided Coax](#) • [DragonSkin 2-Hour Cables](#) • [Digital Electricity™ Cables](#) • [Connectors & Tools](#) • [DragonSkin Connectors & Tools](#) • [DAS Equipment](#)